



GLIDECAM SMOOTH SHOOTER

PROFESSZIONÁLIS KAMERA STABILIZÁTOR RENDSZER



***THE NAME AND FUTURE
OF CAMERA STABILIZATION.™***

THE GLIDECAM SMOOTH SHOOTER PROFESSIONAL CAMERA STABILIZATION SYSTEM

The GLIDECAM SMOOTH SHOOTER is the World's most sophisticated and affordable body mounted Camera Stabilization System designed for Cameras weighing up to 2,7 kg (6 pounds) when used with the Glidecam 2000 Pro, or for Cameras weighing from 2,7 to 4,5 kg (4 to 10 pounds) when used with the Glidecam 4000 Pro. The GLIDECAM SMOOTH SHOOTER system will allow you to walk, run, go up and down stairs, shoot from moving vehicles and travel over uneven terrain without any camera instability or shake.

While the GLIDECAM SMOOTH SHOOTER does not come with a Glidecam 2000 Pro or a Glidecam 4000 Pro, it is specifically designed to be used with them. So, if you already own a Glidecam hand-held stabilizer, you will be able to use it with the SMOOTH SHOOTER by simply attaching it to the end of the Smooth Shooter's Support Arm. Neither the Glidecam 2000 Pro, nor the 4000 Pro need to be modified to work with the GLIDECAM SMOOTH SHOOTER.

When using the GLIDECAM 2000 PRO or GLIDECAM 4000 PRO in hand-held mode, it is your arm that carries all of the weight. However, when the 2000 PRO or 4000 PRO are used with the SMOOTH SHOOTER, it is the SMOOTH SHOOTER'S Spring-loaded Support Arm that carries all of the weight. Because of this, you will now be able to shoot for extended periods of time, whereas before, the stress associated with hand-holding the weight reduced your shooting time.

The GLIDECAM SMOOTH SHOOTER is not just an affordable replacement for the GLIDECAM V-8; it is a highly developed and meticulously engineered, camera stabilization system. Its ability to shoot smooth imagery within its weight range is extraordinary. It out performs all of the competition in its class, yet remains truly economical. The SMOOTH SHOOTER is the realization of the need to stabilize lightweight cameras using the same degree of sophistication employed to stabilize heavy cameras. With the GLIDECAM SMOOTH SHOOTER you will be able to acquire the type of smooth footage you've always dreamed of.

The GLIDECAM SMOOTH SHOOTER System includes: Glidecam Support Vest, Smooth Shooter Support Arm, Docking Bracket, (1) Stainless Steel Arm Post, (1) Aluminum Arm Post, (6) Steel Weight Plates, Hardware and Operations manual.



Glidecam Support Vest



Glidecam Smooth Shooter Arm



***THE NAME AND FUTURE
OF CAMERA STABILIZATION.™***

GLIDECAM SMOOTH SHOOTER PROFESSZIONÁLIS KAMERA STABILIZÁTOR RENDSZER



forgalmazza:

Panaudio Kft.

1092 Budapest, Ferenc krt. 26.

Tel.: 1/456-3003, fax: 1/217-1288

www.videopart.hu, e-mail: studio@videopart.hu